



Manual hot tub

The hot tub can be compared to a warm water bath or a jacuzzi. The biggest difference is that the water is heated by a wood-fired stove. The heat creates a natural circulation in the pipes around the stove that ensures that the water is heated.

The hot tub is equipped with an underwater light and a combined air and water massage system. The controls are located at the back (3 push buttons). The sand filter system works with a timer and ensures that the water remains clean.

The hot tub can be used all year round and has an average heating time of 60 to 90 minutes. This time depends on the starting temperature of the water and the outside temperature.

Once you have a fire, stoke the stove every 20 minutes. When the water approaches the desired temperature, you can stop stoking, turn off the air supply and carefully remove the cover. It is recommended to keep the temperature around 35 degrees. That is warm enough and prevents damage to the tub (from 40 degrees!).

Beware of burning on the stove (pipe) and on the water coming out of the stove's exhaust nozzle. This is about 10 degrees warmer than the water in the hot tub.

Some rules :

- check that there is enough water in the hot tub before lighting the fire (the heater's exhaust nozzle must be under water)
- fill the heater a maximum of 2/3
- take a shower before and after use
- do not leave children in the hot tub without adult supervision
- use by a maximum of 4 - 6 people at a time
- do not forget to replace the cover after use

Enjoy it !